

IP PHONE 420/420G QUICK REFERENCE

PHONE OPERATION

Place calls

Use the handset, the speakerphone, or a headset

Lift handset or press or + ext.

Make a blind conference call

+ ext. +

Make a consultative conference call

+ ext. + wait + to select +

Use the Directory

+ to select +

Dial from History

+ to select +

Note: To close Directory or History, press that key again.

Answer calls

Answer a call

Lift handset or press or

Answer call waiting (incoming call)

Press blinking call appearance button

Answer an off-screen incoming call

Press while offscreen call is displayed

Interact with calls

Adjust volume of handset, headset, or speakerphone when off hook; adjust ringer volume when on hook

to select

Mute a call



Place a call on or off hold

Transfer a call (blind)

+ ext. + hang up or

Transfer a call (with a consultation)

+ ext. + wait + to select +

Divert an incoming call to Voicemail

or

Adjust the display contrast

Press and hold + or

VOICEMAIL

Log in to Voicemail Main Menu

+ Password +

Log in from another extension

+ + Ext. + Password +

Log in or out of workgroup

+ Password + + + + + or

Change availability state

+ Password + +

Change extension assignment

+ Password + +

Unassign extension assignment

+ Password + +

Assign extension to external number

+ Password + +

EXTENSION ASSIGNMENT CODES

Transfer a call

+ destination +

Conference a call

+ destination +

Hold a call

Hang up

Access other star codes

+ (numerical code from list below)

QUICK REFERENCE OF COMMON STAR CODES

Park a call

Unpark a call

Pick up a Remote Extension

Pick up the Night Bell

Use the Intercom

Barge In

Silent Monitor

Toggle the Hunt Group status

+ Hunt Group's ext.

Whisper Page

Silent Coach

TROUBLESHOOTING

View phone information


+ (INFO#)

Reboot your phone


+ (RESET#)

Note: For details about using the phone, see the *IP Phone 420/420g User Guide*.

IP PHONE 420/420G QUICK REFERENCE



PORTS ON THE PHONE



STATUS ICONS

These icons are displayed on the phone to indicate operational status:

-  Off-screen call (on main display)
-  Voicemail message indicator (on main display)
-  Secure call
-  Missed call (on main display and in History)
-  Inbound call (in History)
-  Outbound call (in History)
-  Transferred call (in History)
-  Workgroup Agent logged in
-  Workgroup Agent logged out
-  Workgroup Agent wrap up

GUIDE TO LEDS

Your IP Phone 420/420g provides visual cues about its operational status:

-  Steady Green: Phone is in use (dialing or off hook)
-  Blinking Green (Fast): Call on hold or call parked
-  Blinking Green (Slow): Incoming call